



HISTORY INFORMATION FOR THE FOLLOWING MANUAL:

# ***SERVICE MANUAL***

---

**ORIGINAL MANUAL ISSUE DATE: 3/2015**

**GN1T CHASSIS**  
Segment: XF

<b>Version</b>	<b>Date</b>	<b>Subject</b>
1.0	3/2015	Original manual issue.

**LCD TV**

**SONY®**

9-888-573-01



# ***SERVICE MANUAL***

---

**GN1T CHASSIS**  
Segment: XF

**LCD TV**

**SONY®**

**9-888-573-01**

# MODEL LIST

<u>MODEL</u>	<u>COLOR</u>	<u>COMMANDER</u>	<u>DEST.</u>
<b>XBR-55X850C</b>	Black	RMF-TX100U RMT-TX100U	(LA1)  PUERTO RICO  MX  CHILE, PERU  (UC2)  US/CND
<b>XBR-55X855C</b>	Silver	RMF-TX100U RMT-TX100B	(BR6)  BRAZIL
	Black	RMF-TX100U RMT-TX100B	(CR1)  COSTA RICA  (ECU)  ECUADOR  (LA8)  CHILE  PERU  VENEZUELA
<b>XBR-55X857C</b>	Black	RMF-TX100U RMT-TX100B	(CO1)  COLOMBIA
<b>XBR-65X850C</b>	Black	RMF-TX100U RMT-TX100U	(UC2)  US/CND

<u>MODEL</u>	<u>COLOR</u>	<u>COMMANDER</u>	<u>DEST.</u>
<b>XBR-65X855C</b>	Silver	RMF-TX100U RMT-TX100B	(BR6)  BRAZIL
	Black	RMF-TX100U RMT-TX100B	(AR4)  ARGENTINA  (CR1)  COSTA RICA  (LA8)  CHILE  PERU  VENEZUELA
<b>XBR-65X857C</b>	Black	RMF-TX100B RMT-TX100B	(CO1)  COLOMBIA
<b>XBR-75X850C</b>	Black	RMF-TX100U RMT-TX100U	(LA1)  PUERTO RICO  MX  CHILE, PERU  (UC2)  US/CND
<b>XBR-75X855C</b>	Silver	RMF-TX100U RMT-TX100B	(BR6)  BRAZIL

# **WARNINGS AND CAUTIONS - ENGLISH**

---

## **CAUTION**

These servicing instructions are for use by qualified service personnel only.

To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.

## **WARNING!!**

An isolation transformer should be used during any service to avoid possible shock hazard, because of live chassis.

The chassis of this receiver is directly connected to the ac power line.

## **CARRYING THE TV**

Be sure to follow these guidelines to protect your property and avoid causing serious injury.

- Carry the TV with an adequate number of people; larger size TVs require two or more people.
- Correct hand placement while carrying the TV is very important for safety and to avoid damages.

## **SAFETY-RELATED COMPONENT WARNING!!**

Components identified by shading and  $\Delta$  mark on the schematic diagrams, exploded views, and in the parts list are critical for safe operation. Replace these components with Sony parts whose part numbers appear as shown in this manual or in supplements published by Sony. Circuit adjustments that are critical for safe operation are identified in this manual. Follow these procedures whenever critical components are replaced or improper operation is suspected.

## **CAUTION ABOUT THE LITHIUM BATTERY**

- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- Outer case broken battery should not contact to water.

# **WARNINGS AND CAUTIONS - FRENCH**

---

## **ATTENTION!!**

Ces instructions de service sont à l'usage du personnel de service qualifié seulement.

Pour prévenir le risque de choc électrique, ne pas faire l'entretien autre que celui contenu dans le Mode d'emploi à moins que vous soyez qualifié à faire ainsi.

## **WARNING!!**

Afin d'éviter tout risque d'électrocution provenant d'un châssis sous tension, un transformateur d'isolement doit être utilisé lors de tout dépannage. Le châssis de ce récepteur est directement raccordé à l'alimentation du secteur.

## **POUR TRANSPORTER LE TÉLÉVISEUR**

Tenez compte de ce qui suit pendant l'installation du téléviseur :

- Débranchez tous les câbles avant de transporter le téléviseur.
- Transportez le téléviseur avec le nombre de personnes approprié ; un téléviseur de grande taille doit être transporté par au moins deux personnes.
- Lors du transport du téléviseur, l'emplacement des mains est très important pour votre sécurité, ainsi que pour éviter de causer des dommages.

## **ALERTE!!**

Afin d'éviter tout risque d'électrocution provenant d'un châssis sous tension, un transformateur d'isolement doit être utilisé lors de tout dépannage. Le châssis de ce récepteur est directement raccordé à l'alimentation du secteur.

## **ATTENTION AUX COMPOSANTS RELATIFS A LA SECURITE!!**


Les composants identifiés par une trame et par une marque  sur les schémas de principe, les vues explosees et les listes de pièces sont d'une importance critique pour la sécurité du fonctionnement. Ne les remplacer que par des composants Sony dont le numéro de pièce est indiqué dans le présent manuel ou dans des suppléments publiés par Sony. Les réglages de circuit dont l'importance est critique pour la sécurité du fonctionnement sont identifiés dans le présent manuel. Suivre ces procédures lors de chaque remplacement de composants critiques, ou lorsqu'un mauvais fonctionnement suspecte.

## USE CAUTION WHEN HANDLING THE LCD PANEL

When repairing the LCD panel, be sure you are grounded by using a wrist band.

When repairing the LCD panel on the wall, the LCD panel must be secured using the 4 mounting holes on the rear cover.

- 1) Do not press on the panel or frame edge to avoid the risk of electric shock.
- 2) Do not scratch or press on the panel with any sharp objects.
- 3) Do not leave the module in high temperatures or in areas of high humidity for an extended period of time.
- 4) Do not expose the LCD panel to direct sunlight.
- 5) Avoid contact with water. It may cause a short circuit within the module.
- 6) Disconnect the AC power when replacing the backlight (CCFL) or inverter circuit. (High voltage occurs at the inverter circuit at 650Vrms.)
- 7) Always clean the LCD panel with a soft cloth material.
- 8) Use care when handling the wires or connectors of the inverter circuit. Damaging the wires may cause a short.
- 9) Protect the panel from ESD to avoid damaging the electronic circuit (C-MOS).
- 10) It is recommended not to exceed 1 hour of Power-On nor Burn-in period with LCD panel face down condition, in repair activity.



# SAFETY CHECK-OUT

---

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are “pinched” or touching high-wattage resistors.
3. Check that all control knobs, shields, covers, ground straps, and mounting hardware have been replaced. Be absolutely certain that you have replaced all the insulators.
4. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
5. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
6. Check the line cords for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
7. Check the antenna terminals, metal trim, “metallized” knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.
8. For safety reasons, repairing the Power board and/or Inverter board is prohibited.


## Leakage Test

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes).

Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instructions.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low voltage scale.

The Simpson's 250 and Sanwa SH-63TRD are examples of passive VOMs that are suitable. Nearly all battery-operated digital multimeters that have a 2 VAC range are suitable (see Figure A).




**Figure A.** Using an AC voltmeter to check AC leakage.

## How to Find a Good Earth Ground

A cold-water pipe is a guaranteed earth ground; the cover-plate retaining screw on most AC outlet boxes is also at earth ground.

If the retaining screw is to be used as your earth ground, verify that it is at ground by measuring the resistance between it and a cold-water pipe with an ohmmeter. The reading should be zero ohms.

If a cold-water pipe is not accessible, connect a 60- to 100-watt trouble-light (not a neon lamp) between the hot side of the receptacle and the retaining screw. Try both slots, if necessary, to locate the hot side on the line; the lamp should light at normal brilliance if the screw is at ground potential (see Figure B).



**Figure B.** Checking for earth ground.

# SELF DIAGNOSIS FUNCTION

The units in this manual contain a self-diagnostic function. If an error occurs, the Smart Core Red LED will automatically begin to flash.

The number of times the LED flashes translates to a probable source of the problem.

A definition of the Smart Core Red LED flash indicators is listed in the instruction manual for the user's knowledge and reference.

If an error symptom cannot be reproduced, the remote commander can be used to review the failure occurrence data stored in memory to reveal past problems and how often these problems occur.

## DIAGNOSTIC TEST INDICATORS

When an error occurs, the Smart Core Red LED will flash a set number of times to indicate the possible cause of the problem.

If there is more than one error, the LED will identify the first of the problem areas.

Result for all of the following diagnostic items are displayed on screen.

If the screen displays a “0”, no error has occurred .

<G>: Power supply board, <B>: Main board, <T>: Tcon board,  
<P>: Panel module , <S>: Speaker , <A>: Power Adapter

RED LED blinking count	Detection Items
2x	<G/B> Main 12V over voltage [MAIN_POWER]
3x	<B> Main 5.0V failure [DC_ALERT] <B/S> Audio amp. protection [AUD_ERR] <B> Tuner or demodulator I2C No ACK [TU_DEMOD] <B> HDMI Switch/Equalizer I2C communication error [HDMI_EQ]
4x	None
5x	<P/T/G/B> <i>Panel ID EEPROM I2C No ACK (Also panel power failure is a suspect)</i> [P_ID_ERR] <T> TCon IC I2C communication error [TCON_ERR]
6x	<G/P/B> Backlight failure [BACKLIGHT]
7x	Over temperature protection [TEMP_ERR] <B> Temp. sensor I2C No ACK [TEMP_ERR] <B> V By One lock error between Main device and 4KBE device [4KBE_ERR]
8x	<B> Software error [SW_ERR]

*Red italic:* detect at startup sequence only.

## [SELF DIAGNOSTIC SCREEN DISPLAY]

## Format of error timestamps

YYMMDDhhmmss (in UTC)

Example:

120823132523 -&gt; Aug 23 2012 13:25:23 UTC

\* Only when time is set, an error timestamp is saved.

Smart Core Red LED blinking count

• Panel Operation Time is recorded every 30 min, but Total Operation Time is recorded every 1 hr. Therefore, the panel op. time might become larger than the total op. time.

Error item Naming		SELF CHECK		Error count	
Back					<<
002	MAIN_POWER	000000000000	000000000000	000000000000	000
003	DC_ALERT	000000000000	000000000000	000000000000	000
003	AUD_ERR	150101000018	150101000018	150101000018	003
003	HDMI_EQ	150101000123	15010100045	15010100045	003
003	TU_DEMOD	150101000218	150101000223	150101000105	003
004	LD_ERR	000000000000	000000000000	000000000000	000
004	BCM_ERR	000000000000	000000000000	000000000000	000
005	TCON_ERR	150101000504	000000000000	000000000000	001
005	P_ID_ERR	000000000000	000000000000	000000000000	000
006	BACKLIGHT_ERR	000000000000	000000000000	000000000000	000
007	TEMP_ERR	150101000200	15010100002	000000000000	002
007	4KBE_ERR	000000000000	000000000000	000000000000	000
008	SW_ERR	000000000000	000000000000	000000000000	000
00005 00414 00002		[Home] Exit	Error timestamp for last recorded error	Error timestamp for second last recorded error	Error timestamp for 3rd last recorded error
Total Operation Time [hr] – Boot Count – Panel Operation Time [hr]					

**SELF-DIAGNOSTIC SCREEN DISPLAY**

For errors with symptoms such as “power sometimes shuts off” or “screen sometimes goes out” that cannot be confirmed, it is possible to bring up past occurrences of failure for confirmation on the screen:

**[To Bring Up Screen Test]**

In standby mode, press buttons on the remote commander sequentially in rapid succession as shown below:

**DISPLAY** → Channel **5** → Volume **\*** → **TV POWER**

\* : Note that this differs from entering the service mode (volume +)

Since the diagnostic results displayed on the screen are not automatically cleared, always check the self-diagnostic screen.  
After you have completed the repairs, clear the result display to “0”.

**Clearing the Self Check Diagnostic List**

Panel operation time :

Press the Channel 7 => Channel 0 .

**Exiting the Self-diagnostic screen**

To exit the Self Diagnostic screen, Power off & on or Push the <Home> button.


## **SEC 1. DISASSEMBLY**

---

- There are clutch in the yellow frame[  ]. Therefore please be careful in the case of the disassembly or assembly of parts.


## **1-1. XBR-55X850C/855C/857C**




### **1-1-1. STAND**







## 1-1. XBR-55X850C/855C/857C


## 1-1-2. LABEL, UNDER TERMINAL AND LABEL, REAR TERMINAL AND LABEL, SIDE TERMINAL (L) AND LABEL, CI



**1-1. XBR-55X850C/855C/857C****1-1-3. AC COVER AND POWER SUPPLY CORD**


Screw (SCREW +PSW M4X10) P/N: 4-159-298-01



**1-1. XBR-55X850C/855C/857C****1-1-4. REAR COVER (L HRN) A****1**




- 15 screws (SCREW , +PWH M3X6) P/N: 4-452-935-11
- 8 screws (SCREW, +BVTP 4X12 TYPE2 IT-3) P/N: 2-580-639-01








Ensure R/C is installed to slit of panel.





**2**




Ensure R/C is installed to inside of panel wall.

Ensure R/C is installed to inside of panel wall.


**3**





**1-1. XBR-55X850C/855C/857C****1-1-5. TAPE AND WIRE DRESSING**


**1-1. XBR-55X850C/855C/857C****1-1-6. TAPE AND WIRE DRESSING**




**1-1. XBR-55X850C/855C/857C****1-1-7. SPEAKER BOX ASSY (L)****1****2**

Don't pinch the wire

**3**




**1-1. XBR-55X850C/855C/857C****1-1-8. SPEAKER BOX ASSY (R)****1****2****3**

**1-1. XBR-55X850C/855C/857C****1-1-9. TAPE**

**1-1. XBR-55X850C/855C/857C****1-1-10. BT ANTENNA/WIFI ANTENNA**


## 1-1. XBR-55X850C/855C/857C

### 1-1-11. SMART CORE




#### Notes on assembling the Smart core


Don't scratch O/P with Bezel while installing.





No gap between Smart Core and AL Bezel.






Don't touch these components while installing.




**1-1. XBR-55X850C/855C/857C****1-1-12. SWITCH UNIT****1**

Release the lock



**2****3**



**1-1. XBR-55X850C/855C/857C****1-1-13. HARNESS ASSY (MAIN) AND CONNECTOR ASSY 28P**

CONNECTOR ASSY 28P  
P/N: 1-910-110-23








HARNESS ASSY (MAIN)  
P/N: 1-910-110-24




**1-1. XBR-55X850C/855C/857C****1-1-14. BRACKET,VESA(HWK)****1**

8 screws (SCREW, +PSW M4X8) P/N: 2-580-600-11

**2****3**


**1-1. XBR-55X850C/855C/857C****1-1-15. BRACKET, SC(HWK)**

Confirm BRACKET,SC is installed to hole surely before screwing.




8 screws (SCREW, (+PSW)(M3X6)) P/N: 2-990-421-41

**2**




**3**




## **1-1. XBR-55X850C/855C/857C**


### **1-1-16. SLIDE, CLAMP**






**1**







**2**






**1-1. XBR-55X850C/855C/857C****1-1-17. BOTTOM, FRAME (HRN)****1**



8 screws (SCREW, (+PSW)(M3X6)) P/N: 2-990-421-41

**2****3**


**1-1. XBR-55X850C/855C/857C****1-1-18. BRACKET, SP (LAK)**

8 screws (SCREW, (+PSW)(M3X6)) P/N: 2-990-421-41



**1-1. XBR-55X850C/855C/857C****1-1-19. GL3(CH)-STATIC CONVERTER(TV)****1**




6 screws (SCREW, +PSW M3X6 W12) P/N: 4-256-393-11

**2****3**


## 1-1. XBR-55X850C/855C/857C

### 1-1-20. SHEET, INSULATION(HRN L)

(An insulation sheet is under the GL3 power supply board)






#### Notes on assembling the Insulation sheet (HRN L)




**Caution**

- When handling,
  - Be sure not to touch adhesive tape area.
- After installing,
  - Be sure to push all of adhesive tape area to avoid peel off of "Sheet, Insulation".





## 1-1. XBR-55X850C/855C/857C

### 1-1-21. FLEXIBLE FLAT CABLE 41P (XFS) AND FLEXIBLE FLAT CABLE 51P (XFS)




1




FLEXIBLE FLAT CABLE 41P (XFS)  
P/N: 1-848-915-11 (Except BR6)  
P/N: 1-848-927-11 (BR6)

2




FLEXIBLE FLAT CABLE 51P (XFS)  
P/N: 1-848-914-11 (Except BR6)  
P/N: 1-848-922-11 (BR6)

3



**1-1. XBR-55X850C/855C/857C**

**1-1-22. BRACKET, UNDER FL (MOLD)**




**1**







**2**




**3**




**1-1. XBR-55X850C/855C/857C****1-1-23. BRACKET, SIDE FL (MOLD)****1****2****3**

## **1-1. XBR-55X850C/855C/857C**


### **1-1-24. BRACKET, TOP FL (MOLD)**




**1**





**2**







**3**





**1-1. XBR-55X850C/855C/857C****1-1-25. PLATE, MAIN(HWK) ASSY****1**

5 screws (SCREW, +PSW M3X8) P/N: 2-580-593-01

**2****3**



**1-1. XBR-55X850C/855C/857C****1-1-26. BMFL ASSY****1**

9 screws (SCREW (+PSW)(M3X6)) P/N: 2-990-421-41

**2****3**

## 1-1. XBR-55X850C/855C/857C


### 1-1-27. GASKET (BMF)



**NOTE:**

When you replace a BMFL board, it is necessary to stick five new GASKET on a new BMFL board.  
GASKET (BMF): 4-566-117-01

Stick GASKET inside the guide line.





Guide line  
\*No indication of direction

To stick the GASKET firmly,  
Press the gasket until compression completely.  
(0.5-1.0kgf)





**Caution:**

1. Please aim at the center of square land.
2. Assy the gaskets just before B board panel installation.


**1-1. XBR-55X850C/855C/857C****1-1-28. SHEET, THERMAL(BM) AND PLATE, MAIN(HWK)**

Be careful the side of SHEET THERMAL.




## **1-1. XBR-55X850C/855C/857C**


### **1-1-29. SLIDE, CLAMP**



**1**




**2**




## **1-1. XBR-55X850C/855C/857C**

### **1-1-30. LCD PANEL**




## **1-2. XBR-65X850C/855C/857C**




### **1-2-1. STAND**







**1-2. XBR-65X850C/855C/857C****1-2-2. LABEL, UNDER TERMINAL AND LABEL, REAR TERMINAL AND LABEL, SIDE TERMINAL (L) AND LABEL, CI**


(CO1 ONLY)




**1-2. XBR-65X850C/855C/857C****1-2-3. AC COVER AND POWER SUPPLY CORD**

Screw (SCREW +PSW M4X10) P/N: 4-159-298-01




**1-2. XBR-65X850C/855C/857C****1-2-4. UNDER COVER (2L\_HWK) A****1**


- 12 screws (SCREW , +PWH M3X6) P/N: 4-452-935-11
- 4 screws (SCREW, ORNAMENTAL M6X12) P/N: 4-268-126-02
- 10 screws (SCREW, +BVTP 4X12 TYPE2 IT-3) P/N: 2-580-639-01

**2**

Ensure R/C is installed to slit of panel.




Bottom side

**3**





## 1-2. XBR-65X850C/855C/857C

### 1-2-5. TAPE







## 1-2. XBR-65X850C/855C/857C


## 1-2-6. TAPE




## 1-2. XBR-65X850C/855C/857C

### 1-2-7. WIRE DRESSING




**1-2. XBR-65X850C/855C/857C****1-2-8. SPEAKER BOX ASSY (L)**


1





2






3




**1-2. XBR-65X850C/855C/857C****1-2-9. BRACKET, SP (2L HWK) A**

4 screws (SCREW , +PSW M3X8) P/N: 2-580-593-01




**1-2. XBR-65X850C/855C/857C****1-2-10. SPEAKER BOX ASSY (R)**


1





2





3





**1-2. XBR-65X850C/855C/857C****1-2-11. BRACKET, SP (2L HWK) A****1**

4 screws (SCREW , +PSW M3X8) P/N: 2-580-593-01


**2****3**

## 1-2. XBR-65X850C/855C/857C

## 1-2-12. BRACKET,BT (EGL) ASSY




2




3



4




5




Screw (SCREW (+PSW)(M3X6))

P/N: 2-990-421-41

BRACKET,BT (EGL) ASSY


**1-2. XBR-65X850C/855C/857C****1-2-13. BT ANTENNA/WIFI ANTENNA AND BRACKET, BT(EGL)**

1




2


Screw (SCREW (+PSW)(M3X6))  
P/N: 2-990-421-41



3






4




## 1-2. XBR-65X850C/855C/857C

### 1-2-14. SMART CORE




#### Notes on assembling the Smart core


Don't scratch O/P with Bezel while installing.









No gap between Smart Core and AL Bezel.




Don't touch these components while installing.





**1-2. XBR-65X850C/855C/857C****1-2-15. SWITCH UNIT**



**1-2. XBR-65X850C/855C/857C****1-2-16. HARNESS ASSY (MAIN) AND CONNECTOR ASSY 28P**

CONNECTOR ASSY 28P  
P/N: 1-910-109-95







HARNESS ASSY (MAIN)  
P/N: 1-910-109-96





**1-2. XBR-65X850C/855C/857C****1-2-17. BRACKET,VESA(HWK)****1**




8 screws (SCREW, +PSW M4X8) P/N: 2-580-600-11

**2****3**

**1-2. XBR-65X850C/855C/857C****1-2-18. BRACKET, SC(HWK)****1**



4 screws (SCREW, +PSW M3X8) P/N: 2-580-593-01

**2****3**


**1-2. XBR-65X850C/855C/857C****1-2-19. SLIDE, CLAMP****1****2**

## 1-2. XBR-65X850C/855C/857C



### 1-2-20. BRACKET, STD C (2L\_HWK) AND GASKET (HWK STD)





2 screws (PULLEY, STAND (HWI)) P/N: 4-534-964-01



8 screws (SCREW, +PSW M4X8) P/N: 2-580-600-11






**1-2. XBR-65X850C/855C/857C****1-2-21. GL1A(CH)-STATIC CONVERTER (TV)**

6 screws (SCREW, +PSW M3X6 W12) P/N: 4-256-393-11


## 1-2. XBR-65X850C/855C/857C

### 1-2-22. SHEET, INSULATION(HWK 2L)

(An insulation sheet is under the GL1A power supply board)






#### Notes on assembling the Insulation sheet (HWK 2L)









**Caution**


- When handling,
  - Be sure not to touch adhesive tape area.
- After installing,
  - Be sure to push all of adhesive tape area to avoid peel off of "Sheet, Insulation".




## 1-2. XBR-65X850C/855C/857C

## 1-2-23. TAPE








**1-2. XBR-65X850C/855C/857C****1-2-24. CABLE, FLEXIBLE FLAT 41P AND CABLE, FLEXIBLE FLAT 51P****1**





CABLE, FLEXIBLE FLAT 41P  
P/N: 1-848-870-11 (Except BR6)  
FLEXIBLE FLAT CABLE 41P  
P/N: 1-848-872-11 (BR6)

**2**

CABLE, FLEXIBLE FLAT 51P  
P/N: 1-848-871-11 (Except BR6)  
FLEXIBLE FLAT CABLE 51P  
P/N: 1-848-873-11 (BR6)




**1-2. XBR-65X850C/855C/857C****1-2-25. BRACKET, UNDER FL (MOLD)****1****2****3**


**1-2. XBR-65X850C/855C/857C****1-2-26. BRACKET, SIDE FL (MOLD)****1****2****3**

## **1-2. XBR-65X850C/855C/857C**


### **1-2-27. BRACKET, TOP FL (MOLD)**




**1**





**2**







**3**





**1-2. XBR-65X850C/855C/857C****1-2-28. PLATE, MAIN(HWK) ASSY****1**

5 screws (SCREW, +PSW M3X8) P/N: 2-580-593-01

**2****3**



**1-2. XBR-65X850C/855C/857C****1-2-29. BMFL ASSY****1**

9 screws (SCREW (+PSW)(M3X6)) P/N: 2-990-421-41

**2****3**

## 1-2. XBR-65X850C/855C/857C


### 1-2-30. GASKET (BMF)



**NOTE:**

When you replace a BMFL board, it is necessary to stick five new GASKET on a new BMFL board.  
GASKET (BMF): 4-566-117-01

Stick GASKET inside the guide line.





Guide line  
\*No indication of direction

To stick the GASKET firmly,  
Press the gasket until compression completely.  
(0.5-1.0kgf)





**Caution:**

1. Please aim at the center of square land.
2. Assy the gaskets just before B board panel installation.


**1-2. XBR-65X850C/855C/857C****1-2-31. SHEET, THERMAL(BM) AND PLATE, MAIN(HWK)**

Be careful the side of SHEET THERMAL.




## 1-2. XBR-65X850C/855C/857C

## 1-2-32. CUSHION, CORNER(EGL) AND TAPE




## **1-2. XBR-65X850C/855C/857C**

### **1-2-33. LCD PANEL**




## **1-3. XBR-75X850C/855C**




### **1-3-1. STAND**







## 1-3. XBR-75X850C/855C


### 1-3-2. LABEL, UNDER TERMINAL AND LABEL, REAR TERMINAL AND LABEL, SIDE TERMINAL (L)




**1-3. XBR-75X850C/855C****1-3-3. AC COVER AND POWER SUPPLY CORD**

Screw (SCREW +PSW M4X10) P/N: 4-159-298-01




**1-3. XBR-75X850C/855C****1-3-4. UNDER COVER (3L\_HWK) A**

1




- 13 screws (SCREW , +PWH M3X6) P/N: 4-452-935-11
- 4 screws (SCREW, ORNAMENTAL M6X12) P/N: 4-268-126-02
- 10 screws (SCREW, +BVTP 4X12 TYPE2 IT-3) P/N: 2-580-639-01

2



Ensure R/C is installed to slit of panel.




Bottom side

3




## 1-3. XBR-75X850C/855C







### 1-3-5. TAPE




## 1-3. XBR-75X850C/855C


### 1-3-6. TAPE




**1-3. XBR-75X850C/855C****1-3-7. WIRE DRESSING**

**1-3. XBR-75X850C/855C****1-3-8. SPEAKER BOX ASSY (L)**


1





2






3




**1-3. XBR-75X850C/855C****1-3-9. BRACKET, SP (2L HWK) A****1**

4 screws (SCREW , +PSW M3X8) P/N: 2-580-593-01


**2****3**

**1-3. XBR-75X850C/855C****1-3-10. SPEAKER BOX ASSY (R)**


1



2




3




## 1-3. XBR-75X850C/855C

## 1-3-11. BRACKET, SP (2L HWK) A




1




4 screws (SCREW , +PSW M3X8) P/N: 2-580-593-01

2







3




## 1-3. XBR-75X850C/855C

## 1-3-12. BRACKET,BT (EGL) ASSY



**1-3. XBR-75X850C/855C****1-3-13. BT ANTENNA/WIFI ANTENNA AND BRACKET, BT(EGL)**

1




2




Screw (SCREW (+PSW)(M3X6))

P/N: 2-990-421-41

3






4




## 1-3. XBR-75X850C/855C

### 1-3-14. SMART CORE




#### Notes on assembling the Smart core


Don't scratch O/P with Bezel while installing.











No gap between Smart Core and AL Bezel.





Don't touch these components while installing.







**1-3. XBR-75X850C/855C****1-3-15. SWITCH UNIT**

**1-3. XBR-75X850C/855C****1-3-16. HARNESS ASSY (GBT / MAIN) AND CONNECTOR ASSY, 3P AND CONNECTOR ASSY 9P**



**1-3. XBR-75X850C/855C****1-3-17. BRACKET,VESA(HWK)****1**




8 screws (SCREW, +PSW M4X8) P/N: 2-580-600-11


**2****3**

**1-3. XBR-75X850C/855C****1-3-18. BRACKET, SC(HWK)**


4 screws (SCREW, +PSW M3X8) P/N: 2-580-593-01






**1-3. XBR-75X850C/855C****1-3-19. SLIDE, CLAMP**

**1-3. XBR-75X850C/855C****1-3-20. BRACKET, STD C (2L\_HWK)****1**


Screw (PULLEY, STAND (HWI)) P/N: 4-534-964-01

**2**


4 screws (SCREW, +PSW M4X8) P/N: 2-580-600-11





**3****1**

Screw (PULLEY, STAND (HWI)) P/N: 4-534-964-01

**2**

4 screws (SCREW, +PSW M4X8) P/N: 2-580-600-11

**3**



**1-3. XBR-75X850C/855C****1-3-21. G4-STATIC CONVERTER(TV)**

4 screws (SCREW, +PSW M3X6 W12) P/N: 4-256-393-11

## 1-3. XBR-75X850C/855C


### 1-3-22. SHEET, INSULATION(HWK 3L SYS)

(An insulation sheet is under the G4 power supply board)



#### Notes on assembling the Insulation sheet (HWK 3L SYS)


Adhesive tape area



Caution




- When handling,
  - Be sure not to touch adhesive tape area.
- After installing,
  - Be sure to push all of adhesive tape area to avoid peel off of "Sheet, Insulation".





To avoid coming off from panel



Don't push here.  
There is support pin.

y  
x






**1-3. XBR-75X850C/855C****1-3-23. GL2-STATIC CONVERTER(TV)**

7 screws (SCREW, +PSW M3X6 W12) P/N: 4-256-393-11


## 1-3. XBR-75X850C/855C

### 1-3-24. SHEET, INSULATION(HWK 3L)

(An insulation sheet is under the GL2 power supply board)






#### Notes on assembling the Insulation sheet (HWK 3L)







Caution







- When handling,
  - Be sure not to touch adhesive tape area.
- After installing,
  - Be sure to push all of adhesive tape area to avoid peel off of "Sheet, Insulation".







## 1-3. XBR-75X850C/855C

## 1-3-25. TAPE, FFC (HWK 3L)







**1-3. XBR-75X850C/855C****1-3-26. FLEXIBLE FLAT CABLE 41P AND FLEXIBLE FLAT CABLE 51P**

**1-3. XBR-75X850C/855C****1-3-27. BRACKET, UNDER FL (MOLD)****1****2****3**



## **1-3. XBR-75X850C/855C**


### **1-3-28. BRACKET, SIDE FL (MOLD)**





**1-3. XBR-75X850C/855C****1-3-29. PLATE, MAIN(HWK) ASSY****1**

5 screws (SCREW, +PSW M3X8) P/N: 2-580-593-01

**2****3**



**1-3. XBR-75X850C/855C****1-3-30. BMFL ASSY****1**

9 screws (SCREW (+PSW)(M3X6)) P/N: 2-990-421-41

**2****3**

## 1-3. XBR-75X850C/855C


### 1-3-31. GASKET (BMF)



**NOTE:**

When you replace a BMFL board, it is necessary to stick five new GASKET on a new BMFL board.  
GASKET (BMF): 4-566-117-01

Stick GASKET inside the guide line.



Guide line  
\*No indication of direction

**Caution:**



1. Please aim at the center of square land.
2. Assy the gaskets just before B board panel installation.

To stick the GASKET firmly,  
Press the gasket until compression completely.  
(0.5-1.0kgf)











## 1-3. XBR-75X850C/855C

### 1-3-32. SHEET, THERMAL(BM) AND PLATE, MAIN(HWK)




Be careful the side of SHEET THERMAL.







**1-3. XBR-75X850C/855C****1-3-33. CUSHION, CORNER(EGL) AND TAPE**






## **1-3. XBR-75X850C/855C**

### **1-3-34. LCD PANEL**





**1-4. SMART CORE (M,L)****1-4-1. WLAN / BT MODULE(11AC) ASSY****1****2**

**1-4. SMART CORE (M,L)****1-4-2. WLAN / BT MODULE(11AC)**


**1-4. SMART CORE (M,L)****1-4-3. SHEET, THERMAL (SC)****1-4-4. HEAT SINK L (SC)**

Confirm Position







**1-4. SMART CORE (M,L)****1-4-5. COVER, TOP**

1




2




**1-4. SMART CORE (M,L)****1-4-6. PANEL, ORNAMENT****1**

Guide Pin      Hook


**2**

Hook


**3**

PANEL, ORNAMENT


**2**

**1-4. SMART CORE (M,L)****1-4-7. LIGHT, GUIDE**


1




2




3



**1-4. SMART CORE (M,L)****1-4-8. HSC3\_S\_M MOUNT**


**1-4. SMART CORE (M,L)**

**1-4-9. CASE, BOTTOM (M)**




## 1-5. SMART CORE (L,C)


### 1-5-1. WLAN / BT MODULE(11AC) ASSY









1




2








**1-5. SMART CORE (L,C)****1-5-2. WLAN / BT MODULE(11AC)**

**1-5. SMART CORE (L,C)****1-5-3. SHEET, THERMAL (SC)****1-5-4. HEAT SINK (SC)**


Confirm Position




**1-5. SMART CORE (L,C)****1-5-5. COVER, TOP****1****2**

**1-5. SMART CORE (L,C)****1-5-6. PANEL, ORNAMENT****1**

Guide Pin      Hook





**2**

Hook

**3**


PANEL, ORNAMENT

**2**

**1-5. SMART CORE (L,C)****1-5-7. LIGHT, GUIDE****1****2****3**


## 1-5. SMART CORE (L,C)

### 1-5-8. HSC3\_L MOUNT



**1-5. SMART CORE (L,C)**

**1-5-9. CASE, BOTTOM (L)**




# SEC 2. ADJUSTMENT

## HOW TO ENTER THE SERVICE MODE

- 1) Turn on the main power switch to set in standby mode.
- 2) Press the buttons on the remote commander in the following sequence  
with each interval within 1 sec, then the service mode will be set.

DISPLAY → Channel 5 → Volume + → TV POWER

- 3) Service mode display.



- 4) How to use the remote commander.

Function	The flow of control
Service mode on	<Display><5><Vol Up><Power>
Service mode off	<MENU>/<HOME>
Item up / down	<↑>/ <↓>
Item select left/right	<↔>/<↔>
Execute	<OK>


- 5) After entering service mode, then turn off the power switch.

## Summary of key behavior

Key	Behavior
Menu	Close service menu
Cursor/Enter	Return Previous page, Change portion of focus item, Enter next page of focus item, etc..
Return	Return to previous page, close service menu etc..

## SOFTWARE VERSION

- 1) In Service Mode, select “Model Information”, press “Enter” or “→” button to enter Status Information.




- 2) Press “Enter” or “Return” button to return to Service Mode.



## SERIAL NUMBER EDIT (1)

- 1) In “Service Mode”, select “Model Information” by pressing “↑” or “↓” then pressing “Enter” or “→” button to enter inside.
- 2) Select “Serial Number Edit” by pressing “↑” or “↓” button then pressing “Enter” or “→” button
- 3) Press “↑” or “↓” to input numbers.
- 4) After user input data , press <Enter>.
  - Pop-up dialog appear to confirm input data correct
  - **Serial Number can be set ONLY ONCE**
- 5) Press “→” or “←” button to select YES or NO. Select YES if input data is correct. Select NO if input data is incorrect. Press <Enter> to save answer.




## SERIAL NUMBER EDIT (2)

If YES is selected, the input data is saved into EEPROM.

SERIAL NUMBER EDIT is greyed out and the serial number that has been input is displayed.


User will not able to edit anymore.



If NO is selected, the input data is not saved into EEPROM.


The serial number that has been input is displayed.

User can still edit the Serial Number.



## MODEL NUMBER SETTING

- 1) In “Service Mode”, select “Model Information” by pressing “↑” or “↓” then pressing “Enter” or “→” button to enter inside.
- 2) Select “Model Number Setting” by pressing “↑” or “↓” button then pressing “Enter” or “→” button.
- 3) Press “↑” or “↓” arrow key to scroll Product Name Candidate.  
➤ (e.g. KDL-40X500B CO1,KDL-40X500C BR6)
- 4) Select one Product Name from the list, press <Enter> will pop dialog to inform user to confirm data. Model dependent settings will be overwritten into EEPROM.




## WB ADJUSTMENT


(Please apply when main board or panel is replaced.)

In “Panel/PQ” service mode.

a. Go to “WB Adjustment” category by “↑” or “↓”.



b. To select “WB Adjustment”, press “→” button.



c. To change data , press “←” or “→” on remote commander.




## WB/MURA/CUC DATA TRANSFER

(Please apply when main board or panel is replaced.)

1. In “Panel/PQ” service mode.

- a. Go to “WB/Mura/CUC data transfer” category by “↑” or “↓”.



- b. To select “WB/Mura/CUC data transfer”, press “→” button.

- c. To change data , press “←” or “→” on remote commander.



2. In “WB/Mura/CUC data transfer”.

- a. Select “WB/Gamma data transfer” by pressing “↑” or “↓” on remote commander.  
b. To change the items, press “←” or “→” on remote commander and press “Enter” button.


**Selectable items are:**

- 0. SoC to T-con
  - 1. T-con to SoC
  - 2. Not action
- c. Select “[start]” and press “Enter” button to start transfer.




## HDD PERFORMANCE CHECK


1. In “Service Mode”, select “General Setting” by pressing “↑” or “↓” then pressing “Enter” or “→” button to enter inside.




2. Select “HDD Performance check ” by pressing “↑” or “↓” then pressing “Enter” or “→” button to enter inside.



3. A message "Please wait ..." is displayed during performance check processing.




4. Result **OK** or **NG** will be displayed after performance of HDD is checked




## HDD RE-REGISTRATION

- 1) In “Service Mode”, select “General Setting” by pressing “↑” or “↓” then pressing “Enter” or “→” button to enter inside.
- 2) Select “AAA” by pressing “↑” or “↓” then pressing “Enter” or “→” button to enter inside.



- 3) Result **OK** or **NG** will be displayed after HDD re-registration is succeed/failed.



# SEC 3. TROUBLE SHOOTING

## 3-1. TRIAGE

### Chart of triage information

1. Confirm the claimed symptom.
2. Select that symptom from the chart.
3. Bring all the boards and cables listed for that symptom.
4. Follow the troubleshooting charts in the technical guides to isolate the board.
5. Chart Color Code.

**RED DOT:** Most likely defective part


**BLUE TRIANGLE:** Secondary possible defective part

**BLACK TEXT:** Board that may correct the symptom



Reference	Symptoms - Shutdown. Power LED blinking red diagnostics sequences										No Power	Video - missing or distorted			Remote	Network	Audio	Skype	Smart Core	Bluetooth (BT)
	2	3	4	5	6	7	8	9	10	Stationary colored lines or dots		No video One of Inputs	No video all Inputs							
B* Board	▲	●	▲	▲	▲	●	●			▲	▲	●	●	●	▲	●	▲	▲	▲	▲
G* Board	●	▲	▲	▲	●					●							▲			
H* Board										▲					●				●	
K* Board		▲															●			
Speaker		▲															●			
Wifi & BT Module							●										●	▲		●
LD* Board			●												▲					
V By One FFC				▲								▲		▲						
Tcon				●					▲			▲		▲						
LCD Panel			▲	●	●	▲					●		▲							
Problem	Power	Power	LD	Panel (Communication)	Panel (Backlight)	TEMP	Soft-ware		Emitter											
						Local UART														
		Audio																		
	Local I2C																			

### 3-2. NO POWER

#### 3-2-1. NO POWER-PCU






## 3-2-2. NO POWER-U-Com Failure (1/2)




To the next page


## 3-2-2. NO POWER-U-Com Failure (2/2)



**3-2-3. NO POWER: DC\_OFF\_DET check****3-2-4. NO POWER: DDCONs check**


## 3-2-5. NO POWER: DDCON check




**3-2-6. NO POWER: LDOs check check**

### 3-3. STANDBY LED BLINKING

#### 3-3-1. 2 Times Blinking (Main power Error)





#### 3-3-2. 3 Times Blinking (DC Alert)




### 3-3-3. 3 Times Blinking (Tuner Error)

#### BMF\* board



**3-3-4. 3 Times Blinking (Audio Error)**

## 1) Power Off Checking\*1




## Note 2:


(1) PVDD-GND short check  
Measure impedance between PVDD and GND at C7722, C7762, C7782, C7834.  
If impedance is <100Ω → NG

(2) LDO out short check  
Measure impedance between +3.3V and GND at C7909.  
If impedance is <100Ω → NG



(3) Fuse open check  
Measure impedance of fuse  
F7702, F7704, F7705, F7701 5A (12.5V)  
F7700 3.15A (DDC5V)  
If fuse open → NG



## 2) Power Off Checking\*2






## 3) Power Off Checking\*3




### 3-3-5. 3 Times Blinking (HDMI EQ Error)

#### BMFL/BMFW board





**3-3-6. 4 Times Blinking (LED Voltage Error)**



## 3-3-7. 5 Times Blinking (Panel Communication Error)




## 3-3-8. 6 Times Blinking (Backlight Error)




**3-3-9. 7 Times Blinking (Temperature Error)**


**3-4. NO SOUND****3-4-1. No Sound Audio****3-4-2. No Sound : TUNER**

**3-4-3. No Sound : MHL**


## 3-4-4. No Sound : HDMI1/2/3/4



## 3-5. NO PICTURE



### 3-5-1. No Picture AEP Destination (BMFL/BMFW) SCART




[All voltage measurement using Oscilloscope]

\* → OK Condition : No solder splash can be seen  
→ NG Condition : Solder splash can be seen

\*\* → OK Condition : No part short-circuited  
→ NG Condition : Part short-circuited

### 3-5-2. No Picture AEP Destination (BMFL/BMFW) VIDEO




[All voltage measurement using Oscilloscope]

\* → OK Condition : No solder splash can be seen  
→ NG Condition : Solder splash can be seen

\*\* → OK Condition : No part short-circuited  
→ NG Condition : Part short-circuited

## 3-5-3. No Picture CH/MX/PA/COL/LA (BMFL/BMFW)




[All voltage measurement using Oscilloscope]

\* → OK Condition : No solder splash can be seen  
 → NG Condition : Solder splash can be seen

\*\* → OK Condition : No part short-circuited  
 → NG Condition : Part short-circuited


## 3-5-4. No Picture CH/MX/PA2/NZ/AUS/BR/COL/BR/UC/HK/TW (BMX)



\* → OK Condition : No solder splash can be seen  
→ NG Condition : Solder splash can be seen

\*\* → OK Condition : No part short-circuited  
→ NG Condition : Part short-circuited

### 3-5-5. No Picture J/UC/HK/TW Destination (BMFL/BMFW)




[All voltage measurement using Oscilloscope]

\* → OK Condition : No solder splash can be seen  
→ NG Condition : Solder splash can be seen

\*\* → OK Condition : No part short-circuited  
→ NG Condition : Part short-circuited


### 3-5-6. No Picture J/UC/HK/TW Destination (BMFL/BMFW)




\* → OK Condition : No solder splash can be seen  
→ NG Condition : Solder splash can be seen


\*\* → OK Condition : No part short-circuited  
→ NG Condition : Part short-circuited

## 3-5-7. No Picture : @ Tuner



**3-5-8. FOR 12V LNB Voltage Checking: @ AEP\_W and JP\_SKP**


## 3-5-9. FOR ANALOG TUNING: @ All destination except JP




## Notes:

- Parts for IFOUT\_N line: R6007, FB6002, C6008, R6327, C6301, R6301.
- Parts for IFOUT\_P line: R6008, FB6003, C6009, R6326, C6300, R6300.
- Parts for IFAGC line: R6072, R6009, R6010, R6069, C6302, R6303.


### 3-5-10. FOR DIGITAL TUNING 1: @ TW, NA-ATSC(MX/UC), JP\_SKP and LA-T2(COL)




## 3-5-11. FOR DIGITAL TUNING 2: @ AEP\_W, JP\_SKP, PA\_T2, CH/HK, LA-ISDB(BR/AR) and LA-T2(COL)




## 3-5-12. NO PICTURE: HDMI1




## 3-5-13. NO PICTURE: HDMI2




## 3-5-14. NO PICTURE: HDMI3




## 3-5-15. NO PICTURE: HDMI4




## 3-5-16. NO PICTURE: MHL (BMX)




## 3-5-17. NO CHARGE: MHL (BMX)




### 3-6. SIDE BUTTONS MALFUNCTION



### 3-7. IR REMOTE COMMANDER MALFUNCTION




### 3-8. LIGHT SENSOR ERROR




### 3-9. NETWORK MALFUNCTION

#### 1) Ethernet (Wired)



## 2) Internal Wireless Network malfunction




If Wi-Fi malfunction happens,

- Wi-Fi module
- Harness between WiFi and Bxx
- Bxx board

are suspected.


## 3) Bluetooth malfunction




# SEC 4. DIAGRAMS

## 4-1. BLOCK DIAGRAM


### 4-1-1. UC



## 4-1-2. LA(BR/AR)





## 4-1-3. LA(COL)




## 4-2. CONNECTOR DIAGRAM

XBR-55X850C/855C/857C




**XBR-65X850C/855C/857C**


**XBR-75X850C/855C**

## 4-3. PC BOARD DIAGRAM

BMFL (A SIDE)




**BMFL (B SIDE)**




#### 4-4. CIRCUIT BOARDS LOCATION


**XBR-55X850C/855C/857C**




**XBR-65X850C/855C/857C**




**XBR-75X850C/855C**



**SMART CORE (L,C)**



**SMART CORE (M,L)**



## SEC 5. EXPLODED VIEWS

---


- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark  $\Delta$  are critical for safety. Replace only with part number specified.

The components identified by mark  $\ominus$  contain confidential information. Strictly follow the instructions whenever the components are repaired and/or replaced.


## 5-1. XBR-55X850C/855C/857C

### 5-1-1. REAR COVER




REF. No.	PART No.	DESCRIPTION	MARK
1	4-567-609-01	LABEL, CI	CO1
2	4-563-756-01	LABEL, SIDE TERMINAL (L)	UC2
3	4-563-760-01	LABEL, UNDER TERMINAL	LA1
3	4-563-760-11	LABEL, UNDER TERMINAL	CR1/ECU/LA8/
3	4-563-760-21	LABEL, UNDER TERMINAL	CO1/BR6
4	4-563-764-01	LABEL, REAR TERMINAL	UC2
4	4-563-765-01	LABEL, REAR TERMINAL	except UC2
5	▲ 1-839-695-12	POWER-SUPPLY CORD (WITH CONN.)	CR1/ECU/LA8/BR6
5	▲ 1-839-696-12	POWER-SUPPLY CORD (WITH CONN.)	CO1/UC2/LA1
6	4-297-989-01	AC COVER	BR6
6	4-299-531-01	AC COVER	except BR
7	1-754-952-11	BT ANTENNA	except BR
7	1-754-954-11	BT ANTENNA	BR6
8	1-859-100-11	SPEAKER BOX ASSY (L)	
9	1-859-100-21	SPEAKER BOX ASSY (R)	
10	1-798-510-31	SWITCH UNIT (SM-G-WW)	except BR
10	1-798-510-41	SWITCH UNIT (SM-G-KIT)	BR6
11	4-559-710-01	REAR COVER (L HRN) A	CO1
11	4-559-710-11	REAR COVER (L HRN) A	CR1/ECU/LA8/
11	A-2073-677-A	REAR COVER (L HRN) A	UC2/LA1
			BR6

## 5-1-2. LCD PANEL



REF. No.	PART No.	DESCRIPTION	MARK
51	4-546-441-11	BRACKET, TOP FL (MOLD)	CO1
52	4-546-442-01	BRACKET, SIDE FL (MOLD)	except BR6
52	4-546-442-11	BRACKET, SIDE FL (MOLD)	BR6
53	4-546-443-11	BRACKET, UNDER FL (MOLD)	LA1
53	4-546-443-21	BRACKET, UNDER FL (MOLD)	UC2
53	4-546-443-41	BRACKET, UNDER FL (MOLD)	CR1/ECU/ LA8/CO1
53	4-546-443-61	BRACKET, UNDER FL (MOLD)	BR6
54	A-2072-562-A	COMPLE SVC (XF) BMFL BR6	CR1/ECU/ LA8/BR6
54	A-2072-563-A	COMPLE SVC (XF) BMFL CO1	CO1
54	A-2072-564-A	COMPLE SVC (XF) BMFL UC2	UC2
54	A-2072-565-A	COMPLE SVC (XF) BMFL LA1	LA1
55	1-474-620-11	GL3(CH)-STATIC CONVERTER(TV)	
56	4-565-059-11	SHEET, INSULATION(HRN L)	
*	57	4-546-473-01	BRACET, VESA(HWK)
58	2-650-770-21	SLIDE, CLAMP	
59	4-547-988-01	BRACKET, SP (LAK)	
60	4-562-155-01	BRACKET, SC (HRN)	
61	1-812-102-11	LCD PANEL (Y55QHNDS)	BR6
61	1-812-103-11	LCD PANEL (Y55QHNDB)	except BR6



## 5-1-3. CONNECTORS



REF.NO.	PART No.	DESCRIPTION	MARK
101	1-910-110-23	CONNECTOR ASSY 28P	CN6401(GL3)-CN9000(BMFL)-TCON (1)
102	1-848-915-11	FLEXIBLE FLAT CABLE 41P (XFS)	CN3600(BMFL)-TCON (1) (except BR6 )
102	1-848-927-11	FLEXIBLE FLAT CABLE 41P (XFS)	CN3600(BMFL)-TCON (1) (BR6)
103	1-910-110-24	HARNESS ASSY (MAIN)	CN1000(BMFL)-CN101(HSC3)-WIFI-SM/CN7700(BMFL)-SP (1)
104	1-848-914-11	FLEXIBLE FLAT CABLE 51P (XFS)	CN3601(BMFL)-TCON (1) (except BR6)
104	1-848-922-11	FLEXIBLE FLAT CABLE 51P (XFS)	CN3601(BMFL)-TCON (1) (BR6 )


## 5-1-4. SCREWS

REF.	DESCRIPTION	PART No.
■	SCREW +PSW M4X10	4-159-298-01
□	SCREW , +PWH M3X6	4-452-935-11
●	SCREW, +BVTP 4X12 TYPE2 IT-3	2-580-639-01
☆	SCREW (+PSW)(M3X6)	2-990-421-41
△	SCREW, +PSW M4X8	2-580-600-11
○	SCREW, +PSW M3X8	2-580-593-01
◆	SCREW, +PSW M3X6 W12	4-256-393-11




## 5-2. XBR-65X850C/855C/857C

## 5-2-1. REAR COVER




REF. No.	PART No.	DESCRIPTION	MARK
201	4-567-609-01	LABEL, CI	CO1
202	4-563-756-01	LABEL, SIDE TERMINAL (L)	
203	4-563-760-01	LABEL, UNDER TERMINAL	UC2
203	4-563-760-11	LABEL, UNDER TERMINAL	LA1
203	4-563-760-21	LABEL, UNDER TERMINAL	CO1/CR1/AR4/LA8 /BR6
* 204	4-563-764-01	LABEL, REAR TERMINAL	UC2
204	4-563-765-01	LABEL, REAR TERMINAL	LA1/CO1/CR1 /AR4/LA8/BR6
205	▲ 1-839-692-12	POWER-SUPPLY CORD (WITH CONN.)	AR4
205	▲ 1-839-695-12	POWER-SUPPLY CORD (WITH CONN.)	CR1/LA8/BR6
205	▲ 1-839-696-12	POWER-SUPPLY CORD (WITH CONN.)	UC2/LA1/CO1
206	4-297-989-01	AC COVER	BR6
206	4-299-531-01	AC COVER	UC2/LA1/CO1/CR1 /AR4/LA8
207	1-754-948-11	BT ANTENNA	UC2/LA1/BR6
207	1-754-949-11	BT ANTENNA	CO1/CR1/AR4/LA8
208	1-859-007-11	SPEAKER BOX ASSY (L)	
209	1-859-007-21	SPEAKER BOX ASSY (R)	
210	4-546-824-01	BRACKET, SP (2L HWK) A	UC2/LA1/CO1/CR1 /AR4/LA8
210	4-546-466-01	BRACKET, SP BARE (2L HWK)	BR6
211	1-798-510-31	SWITCH UNIT (SM-G-WW)	UC2/LA1/CO1/CR1 /AR4/LA8
211	1-798-510-41	SWITCH UNIT (SM-G-KIT)	BR6
212	4-546-825-11	UNDER COVER (2L_HWK) A	UC2/LA1/CO1/CR1 /AR4/LA8
212	A-2068-960-A	UNDER COVER (2L_HWK) A	BR6

## 5-2-2. LCD PANEL



REF. No.	PART No.	DESCRIPTION	MARK
251	4-546-441-11	BRACKET, TOP FL (MOLD)	CO1
252	4-546-442-01	BRACKET, SIDE FL (MOLD)	UC2/LA1/CO1/CR 1/AR4/LA8
252	4-546-442-11	BRACKET, SIDE FL (MOLD)	BR6
253	4-546-443-11	BRACKET, UNDER FL (MOLD)	LA1
253	4-546-443-21	BRACKET, UNDER FL (MOLD)	UC2
253	4-546-443-41	BRACKET, UNDER FL (MOLD)	CO1/CR1/AR4/LA8
253	4-546-443-61	BRACKET, UNDER FL (MOLD)	BR6
254	A-2072-562-A	COMPLE SVC (XF) BMFL BR6	CR1/AR4/LA8/BR6
254	A-2072-563-A	COMPLE SVC (XF) BMFL CO1	CO1
254	A-2072-564-A	COMPLE SVC (XF) BMFL UC2	UC2
254	A-2072-565-A	COMPLE SVC (XF) BMFL LA1	LA1
255	▲ 1-474-617-11	GL1A (CH)-STATIC CONVERTER (TV)	
256	4-549-182-01	SHEET, INSULATION(HWK 2L)	
257	4-546-473-01	BRACET,VESA(HWK)	
258	2-650-770-21	SLIDE, CLAMP	
259	4-562-661-01	BRACKET, SC(HWK)	
260	▲ 1-812-104-11	LCD PANEL(A65QVF6S)	BR6
260	▲ 1-812-105-11	LCD PANEL(A65QVF6B)	UC2/LA1/CO1/CR 1/AR4/LA8



## 5-2-3. CONNECTORS



REF.NO.	PART No.	DESCRIPTION	MARK
301	1-910-109-96	HARNESS ASSY (MAIN)	CN1000(BMFL)-CN101(HSC3)-WIFI-SM/CN7700(BMFL)-SP (1)
302	1-910-109-95	CONNECTOR ASSY 28P	CN6401(GL1)-CN9000(BMFL)-TCON (1)
303	1-848-870-11	CABLE, FLEXIBLE FLAT 41P	CN3600(BMFL)-TCON (1) (except BR6)
303	1-848-872-11	FLEXIBLE FLAT CABLE 41P	CN3600(BMFL)-TCON (1) (BR6)
304	1-848-871-11	CABLE, FLEXIBLE FLAT 51P	CN3601(BMFL)-TCON (1) (except BR6)
304	1-848-873-11	FLEXIBLE FLAT CABLE 51P	CN3601(BMFL)-TCON (1) (BR6)


## 5-2-4. SCREWS

REF.	DESCRIPTION	PART No.
■	SCREW +PSW M4X10	4-159-298-01
□	SCREW , +PWH M3X6	4-452-935-11
●	SCREW, +BVT P 4X12 TYPE2 IT-3	2-580-639-01
☆	SCREW (+PSW)(M3X6)	2-990-421-41
△	SCREW, +PSW M4X8	2-580-600-11
○	SCREW, +PSW M3X8	2-580-593-01
◆	SCREW, +PSW M3X6 W12	4-256-393-11
▲	SCREW, ORNAMENTAL M6X12	4-268-126-02




## 5-3. XBR-75X850C/855C

## 5-3-1. REAR COVER




REF. No.	PART No.	DESCRIPTION	MARK
401	4-563-756-01	LABEL, SIDE TERMINAL (L)	
402	4-563-760-01	LABEL, UNDER TERMINAL	UC2
402	4-563-760-11	LABEL, UNDER TERMINAL	LA1
402	4-563-760-21	LABEL, UNDER TERMINAL	BR6
403	4-563-764-01	LABEL, REAR TERMINAL	UC2
403	4-563-765-01	LABEL, REAR TERMINAL	BR6/LA1
404	△ 1-839-695-12	POWER-SUPPLY CORD (WITH CONN.)	BR6
404	△ 1-839-696-12	POWER-SUPPLY CORD (WITH CONN.)	UC2/LA1
405	4-297-989-01	AC COVER	BR6
405	4-299-531-01	AC COVER	UC2/LA1
406	1-754-949-11	BT ANTENNA	
407	1-859-007-11	SPEAKER BOX ASSY (L)	
408	1-859-007-21	SPEAKER BOX ASSY (R)	
409	4-546-824-01	BRACKET, SP (2L HWK) A	UC2/LA1
409	4-546-466-01	BRACKET, SP BARE (2L HWK)	BR6
410	1-798-510-31	SWITCH UNIT (SM-G-WW)	UC2/LA1
410	1-798-510-41	SWITCH UNIT (SM-G-KIT)	BR6
411	4-546-826-11	UNDER COVER (3L_HWK) A	UC2/LA1
411	A-2068-961-A	UNDER COVER (3L_HWK) A	BR6

## 5-3-2. LCD PANEL



REF. No.	PART No.	DESCRIPTION	MARK	
451	4-546-442-01	BRACKET, SIDE FL (MOLD)	UC2/LA1	
451	4-546-442-11	BRACKET, SIDE FL (MOLD)	BR6	
452	4-546-443-11	BRACKET, UNDER FL (MOLD)	LA1	
452	4-546-443-21	BRACKET, UNDER FL (MOLD)	UC2	
452	4-546-443-61	BRACKET, UNDER FL (MOLD)	BR6	
453	▲ 1-474-616-11	G4-STATIC CONVERTER (TV)		
454	▲ 1-474-615-11	GL2-STATIC CONVERTER (TV)		
455	4-549-183-01	SHEET, INSULATION (HWK 3L)		
456	4-549-184-02	SHEET, INSULATION (HWK 3L SYS)		
457	🔒 A-2072-562-A	COMPLE SVC (XF) BMFL BR6	BR6	
457	🔒 A-2072-564-A	COMPLE SVC (XF) BMFL UC2	UC2	
457	🔒 A-2072-565-A	COMPLE SVC (XF) BMFL LA1	LA1	
458	2-650-770-21	SLIDE, CLAMP		
459	4-567-636-01	TAPE, FFC (HWK 3L)		
*	460	4-546-473-01	BRACET, VESA(HWK)	
461	4-562-661-01	BRACKET, SC(HWK)		
462	▲ 1-812-106-11	LCD PANEL (B75QF59S)	BR6	
462	▲ 1-812-107-11	LCD PANEL (B75QF59B)	UC2/LA1	



## 5-3-3. CONNECTORS



REF.NO.	PART No.	DESCRIPTION	MARK
501	1-910-109-97	HARNESS ASSY (GBT/MAIN)	CN6401(G4)-CN9000(BMFL)-TCON/CN1000(BMFL)-CN101(HSC3)-WIFI-SM/CN7700(BMFL)-SP (1)
502	1-910-109-98	CONNECTOR ASSY 9P	CN6803(GL2)-CN6402(G4) (1)
503	1-848-869-11	CONNECTOR ASSY, 3P	CN6102(GL2)-CN6103(G4) (1)
504	1-848-890-11	FLEXIBLE FLAT CABLE 41P	CN3600(BMFL)-TCON (1)
505	1-848-891-11	FLEXIBLE FLAT CABLE 51P	CN3601(BMFL)-TCON (1)


## 5-3-4. SCREWS

REF.	DESCRIPTION	PART No.
■	SCREW +PSW M4X10	4-159-298-01
□	SCREW , +PWH M3X6	4-452-935-11
●	SCREW, +BVTP 4X12 TYPE2 IT-3	2-580-639-01
☆	SCREW (+PSW)(M3X6)	2-990-421-41
△	SCREW, +PSW M4X8	2-580-600-11
○	SCREW, +PSW M3X8	2-580-593-01
◆	SCREW, +PSW M3X6 W12	4-256-393-11
▲	SCREW, ORNAMENTAL M6X12	4-268-126-02



## 5-4. XBR-55X850C/855C/857C


### 5-4-1. SMART CORE (M,L)



REF. No.	PART No.	DESCRIPTION	MARK
601	4-547-392-01	CASE, BOTTOM (M)	BR6
601	4-564-315-01	CASE, BOTTOM (M)	except BR6
602	A-2066-088-A	HSC3_S_M MOUNT	
603	4-547-390-01	LIGHT, GUIDE	BR6
603	4-564-313-01	LIGHT, GUIDE	except BR6
604	4-547-389-01	PANEL, ORNAMENT	BR6
604	4-564-312-01	PANEL, ORNAMENT	except BR6
605	4-547-395-01	COVER, TOP	BR6
605	4-564-317-01	COVER, TOP	except BR6
606	4-547-397-01	BRACKET, WIFI	BR6
606	4-564-318-01	BRACKET, WIFI	except BR6
607	4-566-841-01	HEAT SINK L(SC)	
608	1-458-853-11	WLAN/BT MODULE(11AC)	except BR6
608	1-458-853-21	WLAN/BT MODULE(11AC) BRZ	BR6

## 5-5. XBR-65X850C/855C/857C, 75X850C/855C

### 5-5-1. SMART CORE (L,C)



REF. No.	PART No.	DESCRIPTION	MARK
651	4-547-393-01	CASE, BOTTOM (L)	BR6
651	4-564-316-01	CASE, BOTTOM (L)	except BR6
652	A-2066-086-A	HSC3_L MOUNT	
653	4-547-390-01	LIGHT, GUIDE	BR6
653	4-564-313-01	LIGHT, GUIDE	except BR6
654	4-547-389-01	PANEL, ORNAMENT	BR6
654	4-564-312-01	PANEL, ORNAMENT	except BR6
655	4-547-395-01	COVER, TOP	BR6
655	4-564-317-01	COVER, TOP	except BR6
656	4-547-397-01	BRACKET, WIFI	BR6
656	4-564-318-01	BRACKET, WIFI	except BR6
657	4-547-207-01	HEAT SINK(SC)	
658	1-458-853-11	WLAN/BT MODULE(11AC)	except BR6
658	1-458-853-21	WLAN/BT MODULE(11AC) BRZ	BR6

## 5-6. OTHER PART

### 5-6-1. MISCELLANEOUS

PART No.	DESCRIPTION	MARK
3-876-036-71	UNI-LABEL, BLANK	
4-262-708-04	CLAMPER, CABLE	
4-449-743-01	SCREW, +PSW M5X16	
4-534-964-01	PULLEY, STAND (HWI)	65" /75"
4-535-586-01	BADGE, XBR LOGO(H3.7)	
* 4-547-493-01	HEAT, SINK (MUFF)	
* 4-548-743-01	HOLDER, HS WS (MUF)	
4-549-186-01	SHEET, THERMAL(BM)	
* 4-549-188-01	HOLDER(HS MUF)	
* 4-549-395-01	HEAT SINK (MUFF C)	
4-549-528-11	SHEET, THERMAL (SC)	
4-566-117-01	GASKET (BMF)	
4-567-123-01	GASKET (HWK STD)	
4-570-857-01	BADGE, XBR LOGO (H3.1)	
7-600-031-97	TAPE (3M 1350FB-1)15MMX66M BLK	
* 7-600-040-44	ADHESIVE (SV380C) 333CC GRY	

### 5-6-2. ACCESSORIES

PART No.	DESCRIPTION	MARK
3-876-036-71	UNI-LABEL, BLANK	
4-262-708-04	CLAMPER, CABLE	
1-458-628-21	3D EYEWEARTDG-BT500A(SVC)GA+LA	55" BR6/75" BR6
1-492-949-11	REMOTE COMMANDER (RMF-TX100U)	75" UC2/LA1
		65" except BR6
1-492-949-21	REMOTE COMMANDER (RMF-TX100U)	55" except BR6
1-492-978-21	REMOTE COMMANDER (RMT-TX100U)	BR6
1-492-975-21	REMOTE COMMANDER (RMT-TX100B)	UC2/LA1
		65" CO1/CR1/AR4/LA8
1-492-975-31	REMOTE COMMANDER (RMT-TX100B)	CO1
1-785-504-21	ADAPTOR, CONVERSION	CR1/ECU/LA8
* 1-848-803-11	RCA CONVERSION CABLE	
4-546-910-01	STAND NECK ASSY	
		65" except BR6
A-2069-466-A	STAND NECK ASSY	55" UC2/LA1
4-559-310-01	STAND NECK ASSY (LAK)	65" BR6
A-2073-679-A	STAND, NECK ASSY (LAK)	55" BR6
4-549-374-01	STAND, SHAFT (3L HWK) A	75" UC2/LA1
A-2068-967-A	STAND, SHAFT (3L HWK) A	75" BR6
4-549-373-01	STAND, SHAFT (2L HWK) A	65" except BR6
A-2068-966-A	STAND,SHAFT (2L HWK) A	75" BR6
4-562-159-01	STAND (L HRN) A	65" except BR6
A-2073-680-A	STAND (L HRN) A	55" BR6
* 4-562-216-11	REFERENCE GUIDE	55" BR6
* 4-562-217-31	REFERENCE GUIDE	UC2
* 4-562-220-31	REFERENCE GUIDE	LA1
4-562-222-11	STARTUP GUIDE	AR4
1-845-283-14	IR BLASTER	BR6
4-562-758-01	BAG, SCREW A (EGL)	UC2/LA1
* 4-567-081-01	SCREW, +PSW M6X12	65"/75" except BR6
* 4-567-082-01	SCREW, +PSW M5X20	
4-449-743-01	SCREW, +PSW M5X16	55"

**END**

---

**9-888-573-01**

XBR-55/65X850C, 855C, 857C, 75X850C, 855C

**Sony Visual Products Inc.**

**English**

2015CL08-Data


Made in Japan

© 2015. 3


205

# APPENDIX-1


## How to USB update



## Software update for B board replacement




## Software update for Panel/T-CON replacement




## APPENDIX-2


### Wire Dressing (XBR-55)



## Wire Dressing (XBR-65)



## Wire Dressing (XBR-75)



# APPENDIX-3

## HANDLING GUIDANCE


### Unpacking(1/2)

1. Take out panel from carton box with proper number of operator.



MINIMUM NUMBER OF OPERATOR
XBR-55
2

2. Take out panel straight out from carton box.




When taking out a panel,  
be careful not to hit front panel and back panel.



## HANDLING GUIDANCE

### Unpacking(2/2)

3. Do not hold or press glass (TFT cell).




4. Put in "separator board" between panel and panel.

#### When "vacuum handling jig" is used.



When taking out a panel,  
be careful not to hit next panel module.



\*Please prepare "Separator board" by yourself.

## HANDLING GUIDANCE

### Carrying (1/2)

**DO NOT HOLD PANEL HORIZONTALLY AT ALL TIMES.**



1. Carry panel vertically.



MINIMUM NUMBER OF OPERATOR
XBR-55
2

PANEL WILL WARP IF HANDLED LIKE THIS PICTURE

2. Do not hold glass area(TFT Cell area).






## HANDLING GUIDANCE

### Carrying (2/2)

3. When carrying by only 1 person, hold panel at top and bottom center position.

MINIMUM NUMBER OF OPERATOR
XBR-55
2



4. For large panels, sizes 49" or larger, hold panel by 2 people.



## HANDLING GUIDANCE

### Placing to table

Follow guidelines below.

#### 1. Steps to place panel to table.



(1) Place vertically.

(2) Change hold position.

(3) Place to table.


#### 2. Place panel by 2 people.



#### 3. Place panel within table surface.



#### 4. Table must not have any step.



## HANDLING GUIDANCE

### Others


- 1. Do not press panel during fixing screw.**



- 2. Do not hold or touch glass (TFT cell) at all times.**



- 3. When attaching or detaching vacuum handling jig to panel, maximum force on panel shall be less than 100N total.**



- 4. Operator must wear gloves.  
Do not touch Panel module without gloves.**

